

Input:

Altronix[®] AL4003V - Triple Output Access Control Power Supply/Charger

Overview:

AL4003V multi-output access control power supply/charger is specifically designed for use with access control systems and accessories. The AL4003V converts a 220VAC 50/60Hz input into three (3) individually regulated power-limited outputs (see specifications).

Specifications:

Supervision:

- AC fail supervision • Input 220VAC 50/60Hz, 0.8 amp. • Input fuse rated @ 5A/250V. (form "C" contact rated 1amp @ 28VDC). • Low battery and battery presence supervision Output: (form "C" contact rated 1amp @ 28VDC). • 1.75 amp continuous supply current at 5VDC. • 1.75 amp continuous supply current at 12VDC. Additional Features: • 1.5 amp continuous supply current at 24VDC. • Power supply, enclosure, cam lock and battery leads. • AC input and DC output LED indicators. • 51 mV p/p output ripple. **Enclosure dimensions** (H x W x D approximate): • Short circuit and thermal overload protection. 13.5" x 13" x 3.25" (342.9mm x 330.2mm x 82.55mm) • Output fuse rated at 15A/32V. Enclosure accommodates up to two (2) **Battery Backup** 12VDC/12AH batteries. • Built-in charger for sealed lead acid or gel type batteries. • Automatic switch over to stand-by battery when AC fails. • Maximum charge current 0.7 amp.
- Zero voltage drop when switched over to battery backup.

Stand-by Specifications: (Current is specified on AL3XB input).

Output	4 hr. of Stand-by &	24 hr. of Stand-by &	60 hr. of Stand-by &
	5 Minutes of Alarm	5 Minutes of Alarm	5 Minutes of Alarm
12VDC / 12AH Battery	_	Stand-by = 200mA Alarm = 3.0 amp	—
24VDC / 40AH Battery	Stand-by = 3.0 amp	Stand-by = 1.0 amp	Stand-by = 300mA
	Alarm = 3.0 amp	Alarm = 3.0 amp	Alarm = 3.0 amp

Installation Instructions:

Wiring methods should be in accordance with the National Electrical Code/NFPA 70/NFPA 72/ANSI, and with all local codes and authorities having jurisdiction. Product is intended for indoor use only.

1. Mount unit in the desired location. Mark and predrill holes in the wall to line up with the top two keyholes in the enclosure. Install two upper fasteners and screws in the wall with the screw heads protruding. Place the enclosure's upper keyholes over the two upper screws, level and secure. Mark the position of the lower two holes. Remove the enclosure. Drill the lower holes and install three fasteners. Place the enclosure's upper keyholes over the two upper screws. Install the two lower screws and make sure to tighten all screws (Enclosure Dimensions, pg. 4). Secure enclosure to earth ground. It is recommended to first review the following tables for screw terminals, switch selection and LED status indications. This will greatly facilitate installation hook-up.

Carefully review: Stand-by Specifications

Terminal Identification Table (pg. 1) (pg. 2, 3)(pg. 2)

LED Diagnostics

2. Connect AC power (220VAC 50/60Hz) to the terminals marked [L, N] (Fig. 1, pg. 3). Use 18 AWG or larger for all power connections (Battery, DC output, AC input).

Use 22 AWG to 18 AWG for power-limited circuits (AC Fail/Low Battery reporting).

Keep power-limited wiring separate from non power-limited wiring (115VAC / 60Hz Input, Battery Wires). Minimum 0.25" spacing must be provided.

- 3. Measure output voltage before connecting devices. This helps avoiding potential damage.
- 4. Connect devices to be powered at 5VDC to the terminals marked [+ OUT 3].
- 5. Connect devices to be powered at 12VDC to the terminals marked [+ OUT 2].
- 6. Connect devices to be powered at 24VDC to the terminals marked [+ OUT 1].
- Connect two (2) 12V Stand-by batteries.
 Note: For Access Control applications batteries are optional. When batteries are not used, a loss of AC will result in the loss of output voltage. Batteries must be lead acid or gel type if used. Two (2) 12V Stand-by batteries connected in series to terminals marked [+ BAT] (*Fig. 1, pg. 3*).
- 8. It is required to connect supervisory trouble reporting devices to the outputs marked [AC FAIL, LOW BAT] (*Fig. 1, pg. 3*). Use 22 AWG to 18 AWG for AC Fail & Low Battery reporting. AC Failure will report in 5 minutes.

Maintenance:

Unit should be tested at least once a year for the proper operation as follows:

Output Voltage Test: Under normal load conditions, the DC output voltage should be checked for proper voltage level *(see Terminal Identification Tables).*

Battery Test: Under normal load conditions check that the battery is fully charged, check specified voltage at the battery terminals and at the board terminals marked [+ BAT –] to ensure that there is no break in the battery connection wires.

Note: Maximum charge current under discharge is 0.7 amp.

Note: Expected battery life is 5 years, however it is recommended changing batteries in 4 years or less if necessary.

LED Diagnostics:

AL400XB220 - Power Supply		
LED	ON	OFF
AC (Green)	Normal operation	No AC input
DC (Red)	Normal operation	No DC output

Terminal Identification Tables:

AL400XB220 - Power Supply

Terminal Legend	Function/Description
L, N	220VAC 50/60Hz
- DC +	24VDC @ 3 amp total continuous output (supplies power to ALX3B).
AC Fail NC, C, NO	Indicates loss of AC power, e.g. connect to audible device or alarm panel. Relay normally energized when AC power is present. Contact rating 1 amp @ 28VDC.
Bat Fail NC, C, NO	Indicates low battery condition, e.g. no battery presence. Relay normally energized when DC power is present. Contact rating 1 amp @ 28VDC. Low battery threshold: 24VDC output threshold is set approximately @ 21VDC
- BAT +	Stand-by battery connections. Maximum charge current 0.7 amp.

AL3XB - Power Output Module

Terminal Legend	Function/Description	
-INPUT +	24VDC from power supply (AL400XB220)	
-OUT 1 +	24VDC @ 1.5 amp continuous power-limited output	
- OUT 2 +	12VDC @ 1.75 amp continuous power-limited output.	
- OUT 3 +	5VDC @ 1.75 amp continuous power-limited output.	

Fig. 1







