

# PD4 Power Distribution Module

### Overview:

Altronix PD4 power distribution module converts a single AC or DC input into four (4) individually fused outputs.

# **Specifications:**

# Input:

- 28VAC or 28VDC max., up to 10A.
- Main fuse rated @ 5A/250V.

# Outputs:

- Four (4) individually fused outputs (fuses are rated @ 3.5A; up to 5A fuses may be used)
- Surge suppression.

# Fuse Ratings:

• Fuses are rated @ 3.5A/250V.

### Visual Indicators:

• Power output LED indicator.

### Additional Features:


• Power ON / OFF switch.

# **Board Dimensions** (L x W x H, approximate):

5.25" x 3.25" x 1" (133.4mm x 82.6mm x 25.4mm).

### Installation Instructions:

- 1. Mount PD4 in the desired location/enclosure.
- 2. Connect the desired power supply output to the terminals marked [INPUT] (Fig. 1a). Note: If using DC voltage, left terminal is NEG. (-) and right terminal is POS. (+) (Fig. 1a).
- 3. Measure output voltage before connecting devices. This helps avoiding potential damage. All terminals with common suffix P "1P, 2P..." are the same polarity.
- 4. Set power switch [SW1] to the OFF position.
- 5. Connect each device to the terminal pairs 1 to 4, marked [1P 1N] through [4P 4N].
- 6. Fuses are rated at 3.5A/250V (Replacement fuses can be rated at 5.0A).
- 7. Set power switch [SW1] to the ON position.



F020

