

T2428100220 Open Frame Transformer

Specifications:

Input:

220VAC 50/60 Hz, 0.5A.

Output:


24VAC/100VA (4A) or 28VAC/100VA (3.5A) supply current.

Installation Instructions:

- 1. Mount transformer in the desired location/enclosure (refer to Transformer Drawing and Dimensions below).
- 2. Connect AC power 220VAC, 50/60Hz to primary leads (black and red) (refer to Wiring Configuration).
- 3. Measure output voltage across the secondary leads before connecting devices *(refer to Wiring Configuration)*. This helps avoiding potential damage.
 - Yellow and Brown for 24VAC (open circuit voltage @ 220VAC approx. 26.1VAC).
 - Black and Brown for 28VAC (open circuit voltage @ 220VAC approx. 30.4VAC).
- 4. Connect 24VAC device(s) to Yellow and Brown leads or 28VAC device(s) to Black and Brown leads (refer to Wiring Configuration below).

WARNING: This installation should be made by qualified service personnel and should conform to the National Electrical Code and all local codes.





220VAC, 50/60Hz Input

Transformer Drawing and Dimensions:

